


NOSE GEAR DIMENSIONS

Measurements



NOSE GEAR SIZING CHART

TYPE	"B" Dimensions
1	4 1/8 inches
2	4 7/8 inches
3	5 5/8 inches
4	6 1/2 inches

The "B" dimension is measured from the leading edge to the trailing edge of the nose gear strut fairing. The measurement is parallel to the Bottom of the cowl and at an angle to the nose gear strut. When you get your measurement look at the box above and determine which Type of nose gear fairing you need.

Questions??? Contact Bob at 623-203-9795 or 623-536-0951 or email him bob@fairings-etc.com